JACK

高速平缝机
产品使用说明

使用说明和零件样本下载地址：
PLEASE DOWN LOAD THE MANUAL AND SPARE PARTS FROM THE FOLLOWING WEBSITE:
(Ghfljh Dfmds mDdS GdfDmdsjE mS×0 GdfDfas sm (Gdsds GdfjGds.
POR FAVOR DESCARGAR EL MANUAL Y LIBRO DE PARTES Y REPUESTOS LO SIGUIENTE EN SITIO WEB:
Пожалуйста, загрузите инструкцию по эксплуатации и детальную (список запасных частей) со следующего websaiTa:
http://download.china-jack.com

产品标准代号：QB/T2256-2006
Standard code of the products: QB/T2256-2006

杰克缝纫机
JACK SEWING MACHINE
HTTP://WWW.CHINA-JACK.COM

杰克缝纫机股份有限公司
JACK SEWING MACHINE CO., LTD.
● 总部地址（Address of Company）：
浙江省临江高新技术开发区六北号
No.15 N6 Airport Road, Jiaojiang Hi-tech Industry Park, Zhejiang P.R.C
邮编（P.C）：317016
● 国内销售部（Domestic Trade Department）：
电话（TEL）：0086-0576-85177766 85177880
传真（FAX）：0086-0576-85177770
● 国际部（International Trade Department）：
电话（TEL）：0086-0576-85177751 85177774
传真（FAX）：0086-0576-85177737
● 服务热线：400-887-8899
http://www.chinajack.com
● 终端检测部：西子湖分部：（正常营业）

You will have informed if the file has been revised. Please no sample or standard

使 用 说 明
Operation Manual

开车前的注意事项：
BEFORE OPERATION

1. 油盘内未加油绝不能开车。
2. 机器运转时，从上转片侧看转向应为逆时针方向，注意，不能倒转。
3. 在第一月中，不要选用大尺寸的电动机皮带轮。
4. 确认电动机标牌上标的电压及相位是否正确。

1. Never operate the machine unless its oil pan has has been filled with oil.
2. After setting up the machine, check the direction of motor rotation. To check it, turn the handwheel by, hand to bring the needle down, and turn the power switch ON while observing the handwheel. (The handwheel should turn counterclockwise as observed from the handwheel side.)
3. Do not use a larger motor pulley for the first one month.
4. Confirm that the voltage and phase (single or 3-phase) are correct by checking them against the ratings shown on the motor nameplate.

使用注意事项：
OPERATION PRECAUTIONS

1. 接通电源开关或机器运转时，调勿将手放到针的下排。
2. 机器运转时，请勿将手指伸入线缆针护罩内。
3. 机头翻动及拆三角皮带时，一定要切断电机开关。
4. 操作者离开机器时，必须切断电源。
5. 机器运转期间，注意不允许将头或手以及任何东西靠近上轮「V」形皮带、缝线轮和电动机。
6. 拆拆皮带罩、防护罩、或者其它保护装置时，请勿开动机器。
7. 不要用香蕉水等油漆稀释剂擦洗机头表面。

1. Keep your hands away from the needle when you turn the power switch ON or while the machine is operating.
2. Do not put your fingers into the thread take-up cover while the machine is operating.
3. Be sure to turn the power switch OFF before tilting the machine head or removing the V belt.
4. When an operator leaves from the machine, make sure to turn off the power.
5. During operation, be careful not to allow your or any other person's head or hands to come close to the handwheel, V belt, bobbin winder or motor, Also, do not place anything close to them. Doing so may be dangerous.

6. If your machine is provided with a belt cover, finger guard or any other protectors, do not operate your machine with any of them removed.
7. Don't clean the face of machine head with thinner.

1. 机器的安装(图 1，图 2，图 3，图 4)
1. INSTALLATION (Fig.1,Fig.2,Fig.3,Fig.4)

*油盘安装：
1) 先将油盘支架❶和油盘座垫❷分别套在油盘❸的耳角上，再将油盘❸安装在台板上。
2) 如图所示，安装时要确保两个油盘支架❶顺向操作者一边，两个油盘座垫❷是在有机头连接钩❹的那一侧。
3) 先将机头连接钩座❺安装在台板上，再将机头连接钩❹嵌入底板孔内，最后将机头放置于台板上，且机头连接钩❹要与台板上的机头连接钩座❺相嵌合。

***Installing the oil pan**
1) Firstly, oil pan holder❶and Oil pan cushion❷should be set in the four corners of the oil pan❸, and then install the oil pan❸on the stand & table.
2) As is shown in the chart, making sure that the two oil holders❶are pointing to the operator during the installation and the two oil pan cushions❷are on the side which is with machine head connecting hook❹.
3) Install the machine head connecting hook base❺on the stand & table, and then put the machine head connecting hook❹in the baseplate hole, at last, put the head on the stand & table, making sure machine head connecting hook❹ is nested in the machine head connecting hook base❺which is on the stand & table.


图 1 Fig.1


图 3 Fig.3


图 2 Fig.2


图 4 Fig.4

2. 机器的润滑(图 5，图 6)
2. LUBRICATION (Fig.5, Fig.6)

1. 润滑须知：(图 5)
*开车前：
1) 向油盘②内加缝纫机油(10 号白油)至 HIGH 记号部位 A。(图 5)
2) 当油面低于 LOW 记号 B，应再加油。
3) 加油后，开动机器，观看到油冰飞溅到油窗②上，说明润滑正常。
4) 至于飞溅的油量多少与总润滑油量多少无关。

*注意：
使用新机器或者长期未使用过的机器时，应在每分钟 1800~2200 转的状态下使机器进行十分钟左右的适应性运转。

1. Information on lubrication (Fig.5)
***Before starting the machine**
1) Fill oil pan ② with sewing machine oil (10 white oil) up to HIGH mark A.
2) When the oil level lowers below LOW mark B, refill the oil pan with the specified oil.
3) When you operate the machine after lubrication, you will see splashing oil through oil sight window ② if the lubrication is adequate.
4) Note that the amount of the splashing oil is unrelated to the amount of the lubricating oil.

***Precaution**
When you first operate your machine after set up or after an extended period of disuse, run your machine at 1,800 s.p.m. to 2,200 s.p.m. for about 10 minutes for the purpose of break-in.

2. 面部油量采用油线渗油的方法（图 6）
2. The amount of oil supplied to the face plate parts apply the plug of main shaft to control (Fig.6)

图 5 Fig.5

图 6 Fig.6

3. 面线的穿法(图 7)
3. THREADING THE MACHINE HEAD (Fig. 7)


图 7 Fig 7

4. 缝线张力(图 8)
4. THREAD TENSION (Fig. 8)

1. 面线张力的调节：
1) 根据不同的缝制条件，用支线螺母来调整面线张力。
2) 若把螺母②按顺时针方向（即 A 方向）转动时，面线张力将增大。
3) 若把螺母②按逆时针方向（即 B 方向）转动时，面线张力将减小。
2. 底线张力的调节：
1) 背夹线螺钉②朝顺时针方向（即 C 方向）转动时，底线张力将增大。
2) 背夹线螺钉②朝逆时针方向（即 D 方向）转动时，底线张力将减小。

1. Adjusting the needle thread tension
1) Adjust the needle thread tension using tension adjust nut ① according to the sewing specifications.
2) As you turn nut ① clockwise (in direction A), the needle thread tension will increase.
3) As you turn nut ① counterclockwise (in direction B), the tension will decrease.


图 8 Fig.8

2. Adjusting the bobbin thread tension
1) As you turn tension adjust screw ② clockwise (in direction C), the bobbin thread tension will increase.
2) As you turn screw ② counterclockwise (in direction D), the bobbin thread tension will decrease.

5. 挑线簧(图 9)
5. THREAD TAKE UP SPRING (Fig. 9)

1. 改变挑线簧③的振动量：
1) 旋松定位螺钉②，
2) 把夹线螺钉①朝顺时针方向（即 A 方向）转动时，挑线簧的拉动量将增大。
3) 把夹线螺钉朝逆时针方向（即 B 方向）转动时，挑线簧的拉动量将减小。
2. 改变挑线簧③的张力：
1) 旋松定位螺钉②，取出夹线器(组件)⑤。
2) 旋紧定位螺钉①，并将动夹线螺钉③，
3) 把夹线螺钉②朝顺时针方向（即 A 方向）转动时，挑线簧的张力将增大。
4) 把夹线螺钉②朝逆时针方向（即 B 方向）转动时，挑线簧的张力将减小。

1. Changing the stroke of thread take-up spring ①
1) Loosen setscrew ②.
2) As you turn tension post ① clockwise (in direction A), the stroke of the thread take-up spring will be increased.
3) As you turn the knob counterclockwise (in direction B), the stroke will be decreased.

2. Changing the pressure of thread take-up spring ③
1) Loosen setscrew ②, and take out tension asm ⑤.
2) Loosen setscrew ①, and remove tension post ③.
3) As you turn tension post ③ clockwise (in direction A), the pressure will be increased.
4) As you turn the post counterclockwise (in direction B), the pressure will be decreased.


图 9 Fig. 9

6. 针与旋梭的关系(图 10)
6. THE RELATION BETWEEN THE NEEDLE AND THE HOOK (Fig. 10)

针与旋梭的关系应配合如下：
1) 转动上轮，使针杆位于最低点，再旋松针杆连接杆定位螺钉。
2) 针杆高度的确定
拉动针杆，水平通过内梭内边缘可看到针孔有 1/3~1/2 下漏（机针必须安装到位），机针浮线槽朝左，然后旋紧针杆连接柱螺钉。
3) 旋梭位置的确定
先将旋梭梭尖朝上，转动上轮，针杆从最低点回升时，观察旋梭与机针配合关系，当旋梭梭尖位于机针孔边上缘1. 2mm时且梭尖平面距机针包槽平面0~0.05mm时（保证梭尖位于机针的中心线附位），旋紧旋梭螺钉。

*注意：若间隙太小，会磨损梭尖，若间隙太大，则会引起跳针。
*旋梭更换用什么型号，调换后，也需使用原来的型号。
The relation between the needle and the hook should be as follows;
1) Turn the pulley, make the needle stay the lowest point, then loosen the screw.
2) The height of the needle bar
Pull the needle bar, you can see the pinhle basset 1/3-1/2 level through edge of inside hook (needle must be position). Turn needle cover wire slot left, then tighten setscrew.
3) The hook position
First note the point of hook in the direction, when running strap pulley needle bar risen from the lowest, fhserve cooperate relation of the hook and needle. When hook point above Pinhole about top of 1.2mm and when plane of the hook point from plane of needle short bar 0.05mm (keep the align hook blade point with the center of needle), tighten the hook setscrew.



* Preaution
If the clearance is too small, the tip of the hook will be abraded. If it is too big, it will lead to skip over. * Note that the type of hook to be substituted for, when replacing the hook, shall be in conformity with the very type of the hook installed in the sewing machine of original assemblage.

7. 皮带罩缝线器的装法(图 11，图 12，图 13)
7. INSTALLING THE BELT COVER AND THE BOBBIN WINDER (Fig.11,Fig.12,Fig.13)

1. 安装程序：
1) 在台板上钻四只木螺钉导孔 A、B、C、D。
2) 将罩壳衬垫①装入机壳的缺孔内。
3) 将上轮前罩壳⑤从后面方装入，使上轮套进上轮前罩壳⑤的孔内。
4) 将上轮后罩壳⑥放置在导孔 C、D 上。
5) 用螺钉和垫圈④⑤⑥将上轮前罩壳固定在台壳上，此时前螺钉紧固按贴动轮固在螺钉④为 30kgfcm，螺钉⑥为 25kgfcm，即螺第四用加超过以上程度，也无效果。
6) 盖上上轮前罩盖板⑦。
7) 将上轮后罩壳⑥向后方移动，在上轮后罩壳⑥的缺较部分碰到上轮前罩壳⑤时，再移动 0.5~1mm，然其余螺钉拆卸螺固定。
8) 用木螺钉将绕线器⑧固定缝导孔 A 和 B 上。

1.Installing procedure
1) Drill four wooden screw guide holes A, B, C and D in the machine table.
2) Insert support ① in the tapped hole in the arm.
3) Install the front belt cover ⑤, get the hand wheel in the middle of the hole.
4) Install the back belt cover ⑥ at C and D.
5) Using the screws ④, ⑤ and washer ⑥ fix the front belt cover ⑤ on the support the tightring bridge for the screw ④ is about 30 kgfcm, for the screw ⑤ is about 25 kgfcm.
6) Fix the cover ⑦.
7) Move the back belt cover ⑥ backward until its rubber touches the front belt cover ⑤, then move further more 0.5-1 mm, fix it using the wooden screws and washers.
8) Fix bobbin winder ⑧ at A and B using the wooden screws.

图 11 Fig.11

图 12 Fig.12

图 13 Fig.13

8. 膝提高度的调节(图 14，15 图)
8. ADJUSTING THE HEIGHT OF THE KNEE LIFTER (Fig.14,Fig.15)

1) 用膝提时的标准压脚高度是 10 毫米。
2) 用膝提调整螺钉②可以调节压脚提升量至 13 毫米。
3) 当压脚提升量超过 10 毫米时，不能使处于最低位置的针杆②的底端与压脚③相碰。
1) The standard height of the presser foot lifted using the knee lifter is 10 mm.
2) You can adjust the presser foot lift up to 13 mm using knee lifter adjust screw ①.
3) When you have adjusted the presser foot lift to over 10 mm, be sure that bottom end of needle bar ② in its lowest position does not bir presser foot ③.

图 14 Fig.14

图 15 Fig.15

9. 规格
9. SPECIFICSTIONS

型 号 Application	高速平缝机 HIGH SPEED LOCKSTITCH
缝 料 Sewing material	一般毛料、棉料、中厚料 General wool cloth, cotton cloth, medium weight and medium weight cloth
缝 速 Sewing speed	最大每分钟 3100转 3100rpm(max)
线迹长度 Stitch length	5mm (最大) 5mm (max)
压脚提升高度（缝料时） Presser foot lifting height	12mm (整大) 12mm (max)
机 针 Needle	DB×1 #9～#18 (标准为#14) DP×5 #20～#23 (标准为#21)
润滑油 Lubrication oil	10# 白油 10# white oil